



ASSEMBLY SEQUENCE:
 STEP1 : ASSEMBLY MTL-P55-ADR AND MTL-55 SERIES.
 STEP2 : ASSEMBLY MTL-P2S65(MTL-PL65) AND MTL-P55-ADR.

INSTRUCTION FOR USE